

The durable and proven design elements found in every RJS aluminium window mean that you are assured of a smooth, trouble-free operation.

To ensure your windows continue to look and perform as intended, some simple care and maintenance guidelines should be followed.



CARE & ROUTINE MAINTENANCE

# CARE & ROUTINE MAINTENANCE



## **ALL ALUMINIUM WINDOWS & DOORS**

External aluminium surfaces of windows and doors should be washed with clean water and a mild detergent at least every three months. A soft sponge or similar should be used to avoid scratching the glass or aluminium.

In coastal or industrial areas where the environmental conditions are more demanding, the cleaning program should be carried out on a monthly basis.

Abrasive, chemical cleaners or steel wool should not be used as such methods may result in damage to the glass or aluminium surfaces.

Fly screens can be cleaned by vacuuming or washing thoroughly with a soft brush.

Opening sashes should be operated on a regular basis to ensure the sash hardware continues to move smoothly.

# **SLIDING WINDOWS & SLIDING DOORS**

Sill recesses should be regularly cleaned and kept clear of dust and foreign matter. A brush and vacuum within the track area may be used to do this.

Drainage slots should be checked on a regular basis to ensure they have not become blocked with residual dirt or grime, to allow maximum drainage.

After cleaning, a light silicon spray may be applied to the track and woolpile seals to ensure quiet and smooth operation of the sash.

Door locks should be checked from time to time for satisfactory operation and may require adjustment to compensate for building settlement.

Door rollers are factory set and should not require any adjustment however, due to building settlement an adjustment needs to be made, the door panel must first be lifted to relieve weight from the roller assembly. Adjustment should be made using a cross recess head screwdriver.

# **AWNING/CASEMENT & WINDOWS**

With sashes open, the sash and opening perimeter should be cleaned regularly and kept clear of dust and foreign matter. Drainage holes should be checked to ensure they have not become blocked.

All door and window operating hardware should be cleaned and operated regularly to ensure smooth operation.

Lubricants should not be used on casement stays, as this will affect their operation.

**Double Hung Windows** 

Window jamb tracks should be cleaned regularly and kept clear of dust and foreign matter. Window operating hardware should be cleaned and operated regularly to ensure smooth operation.

### **GLASS**

It is recommended that all glass surfaces be kept clean by prompt removal of all dirt or other contaminants. Clean water and in some instances the addition of a small amount of mild detergent should be used. After washing, any detergent residue must be thoroughly rinsed away with clean water. Under no circumstance is any form of abrasive cleaner to be used. Stubborn dirt or residue should be lightly sponged off to avoid scratching of the glass.

The frequency of cleaning required will depend on environmental conditions such as proximity to the ocean or industrial areas. As a general guide, glass should be cleaned at least quarterly.



**ADDRESS** 5 Cottam Avenue

Bankstown NSW 2200

**TELEPHONE** (02) 9796 1944

**FAX** (02) 9796 1944

**ENQUIRIES** enquiries@rjsaluminium.com.au

**SALES** sales@rjsaluminium.com.au